

Showstopper Remote

Operating Instructions v1.0

Showstopper Remote allows multiple Emergency Stop buttons to be placed throughout your theatre. This provides an additional measure of safety when the automation operator's view is obstructed. Once installed, pressing the Emergency Stop button on any Showstopper remote, or the Showstopper base station will stop every motor in your show.

To install your Showstopper Remote:

1. Switch to "Remote" on output #1 of your Showstopper base station.
2. Connect a Showstopper cable between output #1 on your Showstopper base station and the input (male) port of the Showstopper remote.
3. If using multiple Showstopper Remotes, you may daisy chain remotes using the output (female) port on the Showstopper Remote.
4. At the last Showstopper Remote install a Showstopper Terminator in the output (female) port. The Showstopper Terminator is simply a 5-pin XLR male cable connector with pins #3 & #5 jumped together.
5. Connect your Stagehand controllers to outputs #2-#6 on your Showstopper base.